

Thank you for the purchase of the Lloydz Primary Support Plate

The use of this Support Plate will strengthen the Primary cover in the center area of the clutch's pull, thus reducing the flex that occurs with higher spring pressures.

You'll need a 3 & 4 mm Allen wrench and a small prying device for installation.

- Remove the 2 screws from the decorative cover, gently prying around the outer surface maybe needed to remove the cover.
- Next remove the 3 screws and the inner steel cover
- Clean excessive oil off the primary cover and your ready to install the Lloydz Support Plate.
- Make sure the O-Ring is clean and place it in the original position; a little grease will hold it in place if necessary.
- Install the Lloydz Support plate with the name as shown below. Use the 4 supplied screws to secure it in place.
- Tighten screws to 95 INCH POUNDS or 8 Ft Lbs.

